zenn
CUSTOMER IS KING

How to safely use and clean your ZENN pleasure toy.

1. Each **ZENN** toy must be cleaned before and after each use.
2. Thoroughly clean it with warm water and mild soap.
3. For optimal pleasure use plenty **ZENN** water-based lubricant.
4. During use, pay attention to gradual progress and avoid excessive force insertion or extraction to prevent soft tissue damage.
5. If you feel any pain, discomfort, or burning sensation during use, please stop immediately.
6. If the toy is used for multiple body parts (such as from the anus to the vagina), it must be thoroughly cleaned and disinfected before switching parts, or use condoms for isolation.
7. Avoid sharing the same toy with others.
8. After use, clean thoroughly with warm water and mild soap and dry with a clean towel. Then store your pleasure toy in the original **ZENN** canvas bag in a cool dry place.

zenn
CUSTOMER IS KING

www.zenn.at

HIGH
EUROPEAN
QUALITY

Art. nr. 260031

8 719497 740291

MADE IN PRC

B&C Sales bv • De Ruijterstraat 12 • 6651 ZH • Druten • The Netherlands





Power On/Off Button

Press and hold it for 1.5 seconds to turn on/ offPress it briefly to switch vibration modes




Charging Port



Vibration Modes Indicator

On/Off Button Vibration Modes Switch

Press briefly to activate vibration or switch vibration modes Press and hold it for 3 seconds to turn off vibration function



Charging Cable

Operation Instructions

1.Before use, rinse the product clean with water or mild shower gel, then wipe dry.
2.You may stimulate erogenous zones such as the nipples, or use the product for penetrative pleasure, and activate the vibration function for enhanced stimulation.
3.After use, rinse the product clean with water or mild shower gel, wipe dry, and store it in a cool, dry place.

zenn
CUSTOMER IS KING

Remote Control Power Supply Instructions

1.The remote control requires one 3V button cell battery to operate. If the battery is depleted, please replace it with a new one. Ensure the battery is inserted into the compartment with the correct polarity. If the product will not be used for an extended period, remove the battery promptly.
2.The remote control uses non-rechargeable batteries. Do not attempt to recharge them. Avoid mixing different types of batteries or old and new batteries. Keep batteries away from direct sunlight, fire, excessive heat, and damp environments. Always insert the battery with the correct polarity.

Penis Sleeve Power Supply Instructions

1.Connect the USB cable to a USB power adapter (not included) or a USB port. You may use any compatible USB power adapter for charging.
2.A full charge takes approximately 2 hours. The exact charging time may vary depending on the remaining battery level of the device.
3.Once fully charged, the device provides approximately 1 hour of use. Actual usage time depends on the selected mode—higher vibration consume more power and shorten operation time.
4.Before disposing of the device, the battery must be removed. Ensure the device is powered off when removing the battery. Dispose of the battery safely and in accordance with local regulations.

Warning

1.This product is intended for adult use only and is not a contraceptive device. Keep it out of reach of children.
2.Avoid applying excessive force during use to prevent potential injury.
3.Do not share this product with others. If you experience any discomfort while using it, discontinue use immediately.
4.Regularly inspect the product for damage. Stop using it immediately if any damage is detected.

