

**Zenn**<sup>®</sup>  
CUSTOMER IS KING

HIGH  
EUROPEAN  
QUALITY

[www.zenn.at](http://www.zenn.at)



Art. nr. 130002



MADE IN PRC

B&C Sales bv • De Ruijterstraat 12 • 6651 ZH • Druten • The Netherlands

**Zenn**<sup>®</sup>  
CUSTOMER IS KING

Thank you for choosing this 3-in-1 Deluxe Prostate Massager. This product combines prostate massage, constriction rings, and weight-stretching features for a deep and safe experience.

To ensure safety and hygiene, please read this manual carefully before use.

### Product Diagram

1. Prostate Stimulator Head (105mm length, with two massage beads Ø 33mm / 35mm)
2. Narrow Neck (Ø 13.5mm, for sphincter retention)
3. Base/Handle (contains the vibration unit)
4. Scrotum Locking Ring (40mm inner diameter, flexible)
5. Penis Locking Ring (30mm inner diameter, flexible)
6. Rear Support Tab (15mm high, anti-slip)
7. Vibration Switch (located on the side of the base)

### Battery Installation

1. Ensure the product is turned off.
2. Locate the battery compartment cover on the side of the base. Turn it counter-clockwise according to the arrow direction to open.
3. Insert 1 AAA battery, paying attention to the positive (+) and negative (-) terminals.
4. Screw the cover back on securely. Do not overtighten to avoid damaging the threads.

### Preparation Before Use

1. Cleaning: Before and after each use, clean the product surface with warm water and mild soap or a dedicated toy cleaner. Wipe dry with a soft cloth.
2. Lubrication: Apply a generous amount of water-based lubricant to the massage head, the neck, and the inside of the locking rings. Do not use silicone-based lubricants as they can damage the silicone material.  
Wearing and Operating Instructions

### Step 1: Wearing the Locking Rings

1. Pass the penis through the upper 30mm ring.
2. Pass the scrotum (testicles) through the lower 40mm ring.
3. Adjust the position so the back of the



main unit (the side with the small tab) rests comfortably against the perineum (the area between the anus and the scrotum).

### Step 2: Inserting the Prostate Stimulator

1. Get into a relaxed position (e.g., lying on your side or squatting).
2. Gently press the well-lubricated massage head against the anus and slowly insert it.
3. Once you feel the first massage bead (33mm) pass the sphincter, pause briefly to allow your body to adjust before continuing.
4. Continue inserting until the second massage bead (35mm) is also fully inside. The narrow neck (13.5mm) should now be held by the sphincter, and the base should be flush against the perineum.

### Step 3: Activating the Vibration

1. Press and hold the button on the side of the base for 3 seconds to turn the vibration on.
2. Press briefly to cycle through different vibration modes or intensities.
3. Press and hold for 3 seconds to turn the power off.

### Cleaning and Maintenance

1. Before Removal: Turn off the vibration.
2. After Removal: Rinse off the lubricant with warm water. Use a dedicated cleaner to thoroughly clean all grooves and ring parts.
3. Drying: Wipe dry with a lint-free cloth and store in a cool, ventilated place. Avoid direct sunlight.
4. Storage: It is recommended to store it in a storage pouch to prevent sticking with other silicone toys.

### Safety Information

- Usage Duration: For first-time users or prolonged wear, it is recommended not to exceed 30 minutes per session. You may gradually extend the duration as your body becomes accustomed.
- Comfort: If you experience stinging pain, numbness, or skin discoloration during wear, remove the device immediately and take a break. Although the material is flexible and the rings have some stretch, avoid forcing body parts that are too large into the rings.
- Allergy Test: This product is made of medical-grade silicone. If you are allergic to silicone, please do not use it.
- Hygiene: Do not allow the device to come

into contact with other uncleaned items. Do not share with others.

### Specifications

- Total Length: 135 mm
- Insertable Length: 105 mm
- Massage Bead Diameter: 33 mm / 35 mm
- Neck Diameter: 13.5 mm
- Shaft Diameter: 23 mm
- Penis Ring Inner Diameter: 30 mm
- Scrotum Ring Inner Diameter: 40 mm
- Material Thickness: 7.5 mm
- Weight: 112 g
- Battery: 1 x AAA
- Material: Medical-grade Liquid Silicone

### Battery Tips

- Remove the battery if the product will not be used for an extended period to prevent leakage and damage to the circuitry.
- Replace the battery when vibrations become weak or stop.



**Zenn**<sup>®</sup>  
CUSTOMER IS KING

