



# STRONG ROTATING MASTURBATOR

A DIRTY MIND IS A JOY FOREVER

## User Manual



### Specifications


Product parameters	Product data
Main material	TPE+ABS
Function	10 Vibration Mode & 5 Telescopic Rotation
Product size	3.07*3.07*9.08 in
Net weight	680g
Maximum volume	≤60db
Rated voltage	3.7V
Rated current	1200mah
Charging method	Magnetic charging
Charging time	≈ 120 minutes
Usage time	≈ 70 minutes
Packing list	Masturbator Cup*1, Charging Cable*1, User Manual*1,

### Button Instruction

Name	Instructions for
Vibrate button	Click to switch vibration mode, 10 kinds in total, repeating.
Switch/pause button	Long press for 2 seconds to turn on/off the power; Click to enable pause mode.
Telescopic Rotating button	Press the button to turn on 5 frequency switch, and the cycle is repeated.

1 • ENGLISH

### Product Diagram



### How to use

1. Long press the for 2 seconds to start, the product will go into the first frequency telescopic rotating mode, then will pause to go into standby, the white light will turn on for a long time.
2. In standby mode, click to enter vibration mode. There are 10 frequencies, the first three are low/medium/high speed, and the last seven are frequency conversion.
3. In standby mode, click to enter rotation mode with telescopic function, a total of 5 frequencies. The first three are low speed forward rotation/medium speed reverse rotation/high speed forward rotation, and the last two are positive and negative rotation. Each point changes one rotation frequency at a time, and so on.

2 • ENGLISH

### How to align the probe



### Magnetic Charging

1. First use, be sure to fill it up before use.
2. Power supply mode: use 5-5.5VDC to charge.
3. Product charging method: [use DC 5V] insert USB adapter 3.5 interface cable into the hole for charging or use mobile phone charger for charging.
4. When charging the product, the buttons have no function and cannot be turned on/off.

- When charging: The indicator light flashes
- Charging finished: The light is long and bright

3 • ENGLISH

### Precautions

1. Please use with appropriate lubricant. If you feel uncomfortable during use, please stop using.
2. When assembling, be sure align the double probes before starting the vibration mode.
3. This product is only suitable for adults, please keep away from children and do not mix with other products.
4. The built-in silicone sleeve can be removed for usual cleaning, but the product body can not be immersed in water for a long time.

### Clean & Maintenance

Wash with body wash or soap before and after each use. Avoid charging port and water on probe. Store in a cool, ventilated, dry place, keep away from extreme high or low temperatures.

4 • ENGLISH

### ATTENTION

How to make the Vibration Function work perfectly?



Otherwise, the vibration frequency is almost zero.

5 • ENGLISH



THE BEST GLIDE ASK YOUR SHOP  
A DIRTY MIND IS A JOY FOREVER

Zenn  
CUSTOMER IS KING  
www.zenn.at  
HIGH EUROPEAN QUALITY



Art. nr. 210082



MADE IN PRC  
B&C Sales bv • De Ruijterstraat 12 • 6651 ZH • Druten • The Netherlands

Stroking Flirtatious  
Rotating Telescopic  
Masturbator Cup  
CE  
ROHS  
RECYCLE  
NO WASTE