

User manual

Please read this manual carefully before using the product.

This product is only for people over 18 years of age.



EN

Specifications

Model: A0132

Material: Silicone+ABS

Size: 208*41*42mm

Using time: 1.5H


Vibration modes: 7

Battery capacity: 500mAh

Charger: 5V,1A/2.0A

Warn: do not use a charger over 5V to charge the product

Charging diagram



The indicator light is blinking while charging. The indicator light is always on when full charged.

Features

- Press and hold button  for 2 seconds to power on/off.
- After power on, quick press button  to change vibration modes.

Vibration version

- Button  is the reset key. (click on it the vibrator to be in the strongest vibration mode. At this time, pressing the button  does not work. You need to press the button  again to return the vibrator to the initial state, and then press the button  to switch the modes.



Art. nr. 250003



MADE IN PRC

B&C Sales bv • De Ruijterstraat 12 • 6651 ZH • Druten • The Netherlands