Product diagram

Telescopic frequency control button:
Short press to adjust the frequency of the 10-frequency function,
long press for 3 seconds to turn off the function.
On key+vibration frequency modulation key:
Short press to adjust the 10-frequency vibration intensity,
long press for 3 seconds to turn off all functions.
Heating button:
Short press to turn on heating,
short press to turn off the function.
Remarks:
1. First, long press and turn on the penis switch,
then short press and turn on the remote control main switch
(the red light is on), in order to enter the working state of the remote control.
2. Press to turn the heating on and off.

operation instruction

1. Before use, rinse with water or shower gel and wipe dry immediately;
2. Apply appropriate amount of lubricant to the chest,
or the product can be inserted into the genital and anal area to obtain pleasure.
3. You can turn on the vibration frequency you need.
4. After use, rinse thoroughly with water or shower gel,
dry immediately, and store in a cool place

Remote control power supply instructions
1. To maintain remote operation, A 1.5 dryexells required.
If the battery fails, please replace it with a new one.
The battery should be placed in the battery compartment
with the correct polarity. If the product has not been
used for a long time, please remove the battery in a timely manner.
2. The battery used in this remote control is a non rechargeable battery.
Non rechargeable batteries cannot be charged.
It is recommended not to mix different types of batteries
or old and new batteries. Batteries should not be exposed to
environments such as sunlight, fire, or similar overheating and humidity.
Batteries should be placed with the correct polarity.
3. Before and after each use of this product, please thoroughly clean it.
Before cleaning, ensure that the product is turned off,
the battery is removed, and the product is in a closed (Close) state.

Power supply instructions
1. Connect the USB cable to a USB power adapter
(excluding the accessory) or USB port, and you can use any USB
power adapter for charging.
2. A complete charge takes approximately 1.2-2.0 hours.
The specific charging time may vary depending on the amount
of residual electricity inside this device.
3. The battery life of a fully charged device is approximately 40 to 60 minutes,
depending on the vibration mode you choose. The higher the frequency
of the vibration mode, the faster the battery consumption.
Before abandoning the appliance, the battery must be removed from the appliance.
When removing the battery, the appliance must be powered off and the battery
must be disposed of safely.

Maintenance and upkeep
1. Before and after each use, please use neutral soap and water to clean and dry,
and stay away from extreme high or low temperature environments.
2. Please store this product in a cool, ventilated, and dry place,
ensuring that it is protected from direct sunlight, high temperature,
heavy pressure, humidity, and pollution.
Warning:
1. It is recommended to use lubricating fluid for the first time when using it.
2. Make sure to turn off the power of the dildo and the remote control after use, so as not to affect the use of the battery.
3. Wash with clean water or neutral detergent after use, and dry in a ventilated place after washing.
4. The product is waterproof for life, so it is not recommended to use it directly in water.
5. The heating time is about 4-5 minutes, please use it with caution for people who are sensitive to heat.

THE BEST GLIDE ASK YOUR SHOP
A DIRTY MIND IS A JOY FOREVER

Made in Germany
Powered by Eros

zenn
CUSTOMER IS KING
HIGH EUROPEAN QUALITY
www.zenn.at

Download and Install the App

1. For Android users, scan the QR code on the left using your phone's scanning tool and follow the prompts to download and install the app.

2. For Apple users, search for "s-toys" in the Apple App Store and download and install the app.

Art. nr. 260028

8 719497 737000

MADE IN PRC

B&C Sales bv • De Ruijterstraat 12 • 6651 ZH • Druten • The Netherlands

II. Device Pairing

Click on Figure 1 to bind a new product. A scanning box (Figure 2) will appear. Scan the QR code on the outer packaging or in the user manual. Alternatively, you can enter the product number below the QR code. After successful addition, it will appear as (Figure 3).

Figure 1

Figure 2

Figure 3

Figure 4

Figure 5

Figure 6

Z1655

III. Device Modes

Turn on the device, and activate your phone's Bluetooth, then click the icon (+) above "Find New Product" to embark on your exciting journey with five modes awaiting your exploration.

IV. Automatic Mode

This interface allows customization based on your product's features, with up to 11 frequencies.

Different products have different interfaces, we offer 9 preset automatic mode functions, including heating, electric shock, vibration, intensity, and more.

V. Music Mode

Vibrate according to the music playing on your phones.
Open the and switch to 'vocal music'.

VI. Sound Mode

Click the microphone to speak, the louder the sound, the stronger the vibration.

(Figure 1) represents the microphone off, while (Figure 2) indicates it's on.

Slide left to decrease sensitivity and right to increase it.

Use your finger to drag the white circular marker left or right to control intensity.

Clicking the arrows on either side can also control strength.

Figure 1

Figure 2

VII. Slide Mode

In the slide mode interface, slide your finger from bottom to top to increase vibration intensity.

You can also slide back and forth.

VIII. Remote Mode

Create a room with a room code and share this code with friends, then they can add your code to mutually control devices.

Note: During interaction, the party with the toy should invite the other to control their device.

IX. Contact Us

You can use this interface to provide feedback on any issues you encounter during use.